




## USER INSTRUCTIONS

### Aurelia 102- Nitrile Grey Grip - Nylon Liner with Grey Nitrile Palm Coating

#### **Users Guide: PPE Cat.2 Glove**

These products are classed as Personal Protective Equipment (PPE) by the European PPE Directive 89/686/EEC and have been shown to comply with this Directive through the Harmonised European Standard EN 388: 2016.

**The user must select the appropriate gloves for the task in hand.**

Performance	Glove
Mechanical Testing To EN388	EN388  4121X
Abrasion Resistance	4
Blade Cut Resistance	1
Tear Resistance	2
Puncture Resistance	1
Cut Resistance (EN ISO 13997)	X

Abrasion Resistance	Scale from 1 to 4
Blade Cut Resistance	Scale from 1 to 5
Tear Resistance	Scale from 1 to 4
Puncture Resistance	Scale from 1 to 4
Cut Resistance (EN ISO 13997)	Scale from A to F

They have been subject to a CE type examination performed by:  
CTC Technology Limited, 4 rue Hermann Frenkel 69367 Lyon cedex 07 FRANCE  
Notified Body Number 0075

Glove Sizes (marked according to EN420): 7, 8, 9 & 10

102-7 S/7  
102-8 M/8  
102-9 L/9  
102-10 XL/10

Not suitable for chemical applications These gloves should not be worn when there is a risk of entanglement by moving parts of machines.

Gloves containing natural rubber latex might contain ingredients which are known to be a possible cause of allergies in sensitised persons. If any allergic reaction should occur then medical advice should be obtained immediately.

#### **Cleaning and Maintenance**

These gloves should not be washed or laundered.

New and used gloves should be thoroughly inspected for damage before use. Information regarding protection refers to the working surface, i.e. 'the palm' of the glove, which has been submitted to testing.

The protection levels indicated are only valid for new gloves.